

# THE WILLIAMS TYPEWRITER.

## PRICE LIST OF PARTS, WITH ILLUSTRATIONS.

### MODEL No. 4.

#### WILLIAMS TYPEWRITER CO., DERBY, CONN

No.	Description	Price
1.	Stop Bar Adjusting Screw	\$0.06
2.	" " " Nut	.06
3.	Left Platen Centre	.10
5.	Centre Post Locking Stud	.04
6.	Carriage Lock	.05
7.	Rock Shaft Pivot Screw	.04
8.	" " " Nut	.15
9.	Guide Bar Seat Screw	.05
10.	Corner Post	1.00
11.	Feed Rock Arm Pivot Screw	.03
12.	Guide Roll Screw	.05
13.	Cap Screw	.20
14.	Right Platen Centre, with Clutch	.15
15.	Centre Post	.35
16.	Support Beam Pivot Screw	.03
18.	Guide Roll Tension	.03
19.	Right Platen Centre Nut	.04
20.	Shift Stop Screw	.03
21.	" " " Nut	.04
22.	Spring Case Stud	.15
23.	Rear Guard Plate Screw	.01
"	Left Shift Lever	.01
"	Guide Bar	.01
"	Right Shift Key Lever Screw	.01
26.	Spring Case Bushing	.07
27.	Release Key Screw, Right or Left	.03
28.	Fixed and Movable Dog Screw, large head	.05
29.	Scale Bar Link Screw	.03
30.	Line Space Link	.03
31.	Vertical Release	.03
"	Guide Bar Link	.03
"	Stop Bar Spring	.03
32.	Shift Lock Bushing	.07
33.	Locking Arm Shaft	.15
34.	Line Space Lever Screw, Long	.02
35.	" " " Short	.02
36.	Feed Rack Screw	.02
37.	Scale Bar Ear Screw	.02
38.	Shift Lock	.30
39.	Line Space Stop Screw	.02
40.	Scale Bar Ear Cam Roll Screw	.03
42.	Bell Screw	.01
"	Bell Bracket Screw	.01
"	Bell Trip Bracket Screw	.01
"	Shift Lock	.01
"	Centre Comb	.01
"	Front	.01
"	Front Guard Plate	.01
"	Ink Pan Support	.01
"	Key Lever Fulcrum	.01
"	Locking Arm Support Screw	.01
"	Scale Bar Ear Tension	.01
"	Name Plate	.01
"	Quadrant Guide Plate	.01
"	Rear Anchor Plate	.01
"	" Comb	.01
43.	Guide Roll Bracket	.01
44.	Scroll Screw	.02

NOTE—In ordering, please give the name and number of the parts.

No.		\$0.01
45.	Scroll Bar Screw .. .. .	.03
46.	Carriage Lock Nut Set Screw .. .. .	.03
47.	Space Bar Link .. .. .	.03
48.	"    "    "    Nut .. .. .	.06
49.	Feed Rock Arm Tension Screw .. .. .	.03
50.	"    "    "    "    Nut .. .. .	.05
51.	Bell Hammer .. .. .	.10
52.	Release Key Washer .. .. .	.04
53.	Scale Bar Ear Cam Roll .. .. .	.06
56.	Detent Roll Release Screw .. .. .	.03
57.	Anti-Creep Rack Screw .. .. .	.03
59.	Line Space Adjusting Stud .. .. .	.03
60.	"    "    Lever Stop Pin .. .. .	.02
	"    "    Guide Roll Lug Pin .. .. .	.02
61.	Margin Stop Bar Stop Screw .. .. .	.03
62.	Scale Bar Ear Spring Pin .. .. .	.03
63.	Line Space Stop Screw Nut .. .. .	.04
64.	Right Release Key Stud .. .. .	.01
65.	Hollow Rivets .. .. .	.01
66.	Guide Roll .. .. .	.30
67.	Line Space Pawl Stud .. .. .	.01
69.	Detent Roll .. .. .	.02
70.	"    "    Pin .. .. .	.01
71.	Pressure Roll Tube End .. .. .	.04
72.	Auxiliary Locking Bar Stud .. .. .	.02
	"    "    Guide Bar Link Stud .. .. .	.02
	"    "    Line Space Lever .. .. .	.02
	"    "    Release Key Stud, Left .. .. .	.02
73.	Type Guide Pin .. .. .	.02
74.	Dog Screw Nut, .. .. .	.04
75.	Stop Bar Stud .. .. .	.02
76.	Margin Stop Pawl Rivet .. .. .	.02
77.	Inner Margin Stop Rivet .. .. .	.02
	"    "    Scroll Rivet .. .. .	.02
79.	Quadrant Fulcrum Rod Screw .. .. .	.05
80.	Scale Bar Link Pin .. .. .	.01
81.	Right Shift Key Stem Pin .. .. .	.01
82.	"    "    "    Stem .. .. .	.05
83.	Locking Rod Nut .. .. .	.06
84.	Final Stop Stud (10 to the inch) .. .. .	.04
85.	Guide Roll Bushing .. .. .	.04
87.	Key Lever Fulcrum Rod .. .. .	.15
88.	Fulcrum Rod Pin .. .. .	.02
89.	Quadrant Fulcrum Rod Clamp .. .. .	.03
90.	"    "    "    "    Screw .. .. .	.03
91.	Escapement Wheel Screw .. .. .	.05
94.	Spring Case Screw .. .. .	.04
95.	Margin Stop Bar Screw .. .. .	.03
96.	Movable Dog Screw, small head .. .. .	.03
97.	Stop Screw Final (9 to the inch) .. .. .	.05
98.	Comb Guard Screw .. .. .	.02
100.	Platen Centre Nut, Left .. .. .	.03
101.	Scale Bar Screw .. .. .	.02
102.	Space Key Screw (Wood) .. .. .	.01
103.	Comb Screw, Front .. .. .	.01
104.	Platen Adjust Screw, Short .. .. .	.02
105.	"    "    "    Medium .. .. .	.02
106.	"    "    "    Long .. .. .	.02
350.	Carriage Spring .. .. .	.25
351.	Key Lever .. .. .	.02
352.	Scale Bar Tension Spring .. .. .	.04
353.	Margin Stop Pawl .. .. .	.01
354.	Feed Rock Arm Tension Spring .. .. .	.02
355.	Movable Dog .. .. .	.03
357.	Carriage Shift .. .. .	.02
358.	Release Key .. .. .	.01
359.	Shift Key Spring, Right .. .. .	.01
360.	Guide Roll Tension Spring .. .. .	.01
361.	Stop Bar Spring .. .. .	.01
362.	Vertical Release Spring .. .. .	.02
363.	Margin Paper Guide Spring .. .. .	.01

NOTE—In ordering, please give the name and number of the parts.



No.											
1203.	Spring Case	..	..	..	..	..	..	..	..	..	\$0.10
1204.	"    "    Gear	..	..	..	..	..	..	..	..	..	.30
1206.	"    "    Ratchet	..	..	..	..	..	..	..	..	..	.02
1207.	"    "    Pawl	..	..	..	..	..	..	..	..	..	.05
	"    "    and Gear	..	..	..	..	..	..	..	..	..	.40
	Spring Case and Gear with Spring, Screw and Bushing	..	..	..	..	..	..	..	..	..	1.00
1208.	Feed Rock Arm	..	..	..	..	..	..	..	..	..	.15
	"    "    Complete with Dogs and Spring	..	..	..	..	..	..	..	..	..	1.00
1209.	Fixed Dog	..	..	..	..	..	..	..	..	..	.10
1210.	Movable Dog	..	..	..	..	..	..	..	..	..	.25
1211.	Vertical Release	..	..	..	..	..	..	..	..	..	.05
1212.	Anti-Creep Rack	..	..	..	..	..	..	..	..	..	.25
1213.	Ball Yoke Complete	..	..	..	..	..	..	..	..	..	.20
1214.	"    "    Pinion	..	..	..	..	..	..	..	..	..	.01
1216.	Rock Shaft	..	..	..	..	..	..	..	..	..	.75
1250.	Carriage Rail	..	..	..	..	..	..	..	..	..	6.00
1251.	Platen	..	..	..	..	..	..	..	..	..	2.50
1255.	Line Space Lever	..	..	..	..	..	..	..	..	..	.55
	"    "    complete with Link	..	..	..	..	..	..	..	..	..	.60
1256.	"    "    Adjust	..	..	..	..	..	..	..	..	..	.25
1257.	"    "    "    Guard	..	..	..	..	..	..	..	..	..	.03
1258.	"    "    Pawl	..	..	..	..	..	..	..	..	..	.05
1259.	"    "    Driving Arm	..	..	..	..	..	..	..	..	..	.10
	"    "    "    with Pawl, Spring and Stud Complete	..	..	..	..	..	..	..	..	..	.25
1260.	"    "    Lever Link	..	..	..	..	..	..	..	..	..	.01
1261.	"    "    Washer	..	..	..	..	..	..	..	..	..	.01
1262.	Margin Stop Bar	..	..	..	..	..	..	..	..	..	1.25
1263.	"    "    Outer (Left)	..	..	..	..	..	..	..	..	..	.25
1264.	"    "    "    (Right)	..	..	..	..	..	..	..	..	..	.25
1265.	"    "    Inner (Left)	..	..	..	..	..	..	..	..	..	.35
1267.	"    "    "    (Right)	..	..	..	..	..	..	..	..	..	.35
1269.	"    "    Pawl	..	..	..	..	..	..	..	..	..	.10
	"    "    "    Bar Complete with Stops	..	..	..	..	..	..	..	..	..	2.55
1270.	Pressure Roll	..	..	..	..	..	..	..	..	..	1.50
1271.	Scale Bar	..	..	..	..	..	..	..	..	..	1.00
	"    "    Complete, with Paper Guides	..	..	..	..	..	..	..	..	..	2.80
1273.	"    "    Ear (Right)	..	..	..	..	..	..	..	..	..	.20
1274.	"    "    "    (Left)	..	..	..	..	..	..	..	..	..	.20
1275.	"    "    Link (Right or Left)	..	..	..	..	..	..	..	..	..	.10
1276.	Pressure Roll Release, (Right or Left)	..	..	..	..	..	..	..	..	..	.02
1278.	Margin Paper Guide, (Right or Left)	..	..	..	..	..	..	..	..	..	.40
1279.	Feed Rack	..	..	..	..	..	..	..	..	..	.30
1280.	Release Bar,	..	..	..	..	..	..	..	..	..	.12
	"    "    with Left Release Key	..	..	..	..	..	..	..	..	..	.35
1281.	"    "    Key (Right)	..	..	..	..	..	..	..	..	..	.20
1282.	"    "    "    (Left)	..	..	..	..	..	..	..	..	..	.20
1283.	Guide Roll Bracket,	..	..	..	..	..	..	..	..	..	.10
	"    "    "    Complete with Roller	..	..	..	..	..	..	..	..	..	.75
1284.	"    "    "    Lug	..	..	..	..	..	..	..	..	..	.10
1285.	Front Scroll	..	..	..	..	..	..	..	..	..	.25
1286.	Back	..	..	..	..	..	..	..	..	..	.25
	"    "    Complete	..	..	..	..	..	..	..	..	..	2.00
1287.	"    "    Brace	..	..	..	..	..	..	..	..	..	.05
1288.	"    "    Bracket	..	..	..	..	..	..	..	..	..	.05
1289.	Paper Table	..	..	..	..	..	..	..	..	..	.10
1290.	Front Scroll Bar	..	..	..	..	..	..	..	..	..	.10
1291.	Scale Bar Ear Tension Bracket	..	..	..	..	..	..	..	..	..	.05
1292.	Detent Roll Release	..	..	..	..	..	..	..	..	..	.05
1293.	Platen Centre Lock	..	..	..	..	..	..	..	..	..	.05
1294.	Platen Knob	..	..	..	..	..	..	..	..	..	.15
1300.	Escapement Wheel	..	..	..	..	..	..	..	..	..	.75
1307.	Carriage Guide Hook	..	..	..	..	..	..	..	..	..	.01
1312.	Platen Brake	..	..	..	..	..	..	..	..	..	.15
1313.	Type	..	..	..	..	..	..	..	..	..	.20
1316.	Trip Bar Cork Loop	..	..	..	..	..	..	..	..	..	.05
1328.	Bell	..	..	..	..	..	..	..	..	..	.30
1329.	Guide Roll Ball	..	..	..	..	..	..	..	..	..	.05
1330.	Carriage Ball	..	..	..	..	..	..	..	..	..	.10
1331.	Space Bar Buffer	..	..	..	..	..	..	..	..	..	.01
1332.	"    "    Cushion	..	..	..	..	..	..	..	..	..	.01

NOTE—In ordering, please give the name and number of the parts.





